



Switch Positions:
 O = Open for V_{oc}
 S = Short for I_{sc}
 L = Load for I_{load} , V_{load}

Meter wires 18 gauge,
 Test wires 12 gauge,
 All stranded.
 Use standard DMM
 probes to calibrate.